Postal address: Phone: Fax: Email: Internet:

Delivery address: Mackenrodtstraße 14 36039 Fulda, Germany 36035 Fulda, Germany +49 661 6003-0 +49 661 6003-607 mail@jumo.net www.jumo.net

JUMO Instrument Co. Ltd. JUMO House Temple Bank, Riverway Harlow, Essex, CM20 2DY, UK Phone: +44 1279 63 55 33 Fax: +44 1279 62 50 29 Email: sales@jumo.co.uk Internet: www.jumo.co.uk

JUMO Process Control, Inc. 6733 Myers Road East Syracuse, NY 13057, USA Phone: +1 315 437 5866 +1 315 437 5860 Fax: Email: info.us@jumo.net Internet: www.jumousa.com



Data Sheet 202670

Page 1/11

JUMO ecoLine NTU

Optical Sensor for Turbidity Measurements

Brief description

The turbidity measurement according to DIN EN ISO 7027 is a tried and tested method for monitoring waters with low to strong turbidity.

The measuring principle of the JUMO ecoLine NTU turbidity sensor is based on an infrared light measurement according to the 90 ° scattered light method. Thanks to the light measurement at a wavelength of 880 nm and the wide measuring range of 0 to 4,000 NTU, the sensor can be used in an array of water and wastewater treatment applications, e.g. for monitoring the water quality, detecting filter leaks, and for wastewater final inspection.

The JUMO ecoLine NTU stores its calibration data and history directly in the sensor electronics, meaning that it can be used quickly anywhere without the need for constant recalibration.

The sensor is characterized by its slim and robust design.

Suitable fittings are required for the installation of the sensor, e.g. in order to prevent the influence of extraneous light and the resulting measurement errors. For the corresponding immersion, suspended, and flow fittings that are available, see page chapter "Fittings", page 7.

The robust, simple sensor is particularly well-suited to the following areas of application:

- Drinking water treatment
- Water protection
- Fish farming companies
- Municipal and industrial sewage treatment plants
- Process plants
- Paper industry



Type 202670/...

Fax: Email: Internet:

Delivery address: Mackenrodtstraße 14 36039 Fulda, Germany Postal address: 36035 Fulda, Germany Phone: +49 661 6003-0 +49 661 6003-607 mail@jumo.net www.jumo.net

JUMO Instrument Co. Ltd. JUMO House Temple Bank, Riverway Harlow, Essex, CM20 2DY, UK Phone: +44 1279 63 55 33 Fax: +44 1279 62 50 29 Email: sales@jumo.co.uk Internet: www.jumo.co.uk

JUMO Process Control, Inc. 6733 Myers Road East Syracuse, NY 13057, USA Phone: +1 315 437 5866 Fax: +1 315 437 5860 Email: info.us@jumo.net Internet: www.jumousa.com



Data Sheet 202670

Page 2/11

Technical data

Specifications

Measuring principle	Optical, nephelometric turbidity measurement with 90 ° scattered light according to DIN EN ISO 7027	
Measurands	Turbidity Temperature	
Measuring ranges	 0 to 4,000 NTU in a choice of 4 measuring ranges as well as automatic measuring range detection: 0.00 to 50.00 NTU 0.0 to 200.0 NTU 0 to 1,000 NTU 0 to 4,000 NTU 	
Resolution	0.01 to 1, depending on measuring range	
Accuracy	< 5 % from NTU measured value	
Max. sampling rate for measured values	1 Hz	
Temperature range	0 to +50 °C	
Pressure range	Up to 5 bar	
Storage temperature	-10 to +60 °C	

Interfaces

Signal interface	RS485 interface with Modbus RTU protocol ^a
^a Only in connection with suitable Modbus master devices, see "Display unit / controller" on page 2.	

Electrical data

Voltage supply	DC 5 to 12 V	
Current consumption		
Standby	40 μΑ	
RS485 on average	820 μA (at 1 measurement per second)	
Current pulse (starting current peak)	500 mA, heat-up time: 100 ms	
Connection	4-conductor shielded cable, optionally with open conductor ends with ferrules or with M12 plug	
Electromagnetic compatibility	Acc. to EN 61326-1	
Interference emission	Class A	
Interference immunity	Industrial requirements	

Case

Dimensions	Ø 27 mm × 147 mm (sensor case without cable)	
Weight		
Sensor including 10 m cable	720 g	
Sensor including 30 m cable	1,850 g	
Length of permanent cable	10 m, 30 m	
Materials		
Sensor case	PVC, POM-C	
Optical window	PMMA	
Connection cable	polyamide	
Protection type	IP68	

Postal address: Phone: Fax: Email: Internet:

Delivery address: Mackenrodtstraße 14 36039 Fulda, Germany 36035 Fulda, Germany +49 661 6003-0 +49 661 6003-607 mail@jumo.net www.jumo.net

JUMO Instrument Co. Ltd. JUMO House Temple Bank, Riverway Harlow, Essex, CM20 2DY, UK Phone: +44 1279 63 55 33 Fax: +44 1279 62 50 29 Email: sales@jumo.co.uk Internet: www.jumo.co.uk

JUMO Process Control, Inc. 6733 Myers Road East Syracuse, NY 13057, USA Phone: +1 315 437 5866 Fax: +1 315 437 5860 Email: info.us@jumo.net Internet: www.jumousa.com



Data Sheet 202670

Page 3/11

Display unit / controller



Postal address: Phone: Fax: Email: Internet:

Delivery address: Mackenrodtstraße 14 36039 Fulda, Germany 36035 Fulda, Germany +49 661 6003-0 +49 661 6003-607 mail@jumo.net www.jumo.net

JUMO Instrument Co. Ltd. JUMO House Temple Bank, Riverway Harlow, Essex, CM20 2DY, UK Phone: +44 1279 63 55 33 Fax: +44 1279 62 50 29 Email: sales@jumo.co.uk Internet: www.jumo.co.uk

JUMO Process Control, Inc. 6733 Myers Road East Syracuse, NY 13057, USA Phone: +1 315 437 5866 Fax: +1 315 437 5860 Email: info.us@jumo.net Internet: www.jumousa.com



Data Sheet 202670

Page 4/11

Dimensions



(1) RS485 connection cable (fixed cable)

- (2) Laser engraving indicating the sensor type and part no.
- (3) Infrared transmitter and receiver
- (4) Temperature sensor

Postal address: Phone: Fax: Email: Internet:

Delivery address: Mackenrodtstraße 14 36039 Fulda, Germany 36035 Fulda, Germany +49 661 6003-0 +49 661 6003-607 mail@jumo.net www.jumo.net

JUMO Instrument Co. Ltd. JUMO House Temple Bank, Riverway Harlow, Essex, CM20 2DY, UK Phone: +44 1279 63 55 33 Fax: +44 1279 62 50 29 Email: sales@jumo.co.uk Internet: www.jumo.co.uk

JUMO Process Control, Inc. 6733 Myers Road East Syracuse, NY 13057, USA Phone: +1 315 437 5866 Fax: +1 315 437 5860 Email: info.us@jumo.net Internet: www.jumousa.com



Data Sheet 202670

Page 5/11

Electrical connection

Fixed cable with ferrules

The cables with ferrules are connected without tension or soldering, using screw-type plug-in terminals of the display unit/controller.



Fixed cable with M12 plug, A-coded

For connection to the JUMO digiLine bus.

Function	Pin	Figure
+5 V voltage supply from the display unit/controller	1	
not connected	2	
GND	3	
RS485 B (RxD/TxD-)	4	●1 ●5 ●3
RS485 A (RxD/TxD+)	5	
	1	

 Delivery address:
 Mackenrodtstraße 14 36039 Fulda, Germany

 Postal address:
 36035 Fulda, Germany

 Phone:
 +49 661 6003-0

 Fax:
 +49 661 6003-0

 Email:
 mail@jumo.net

 Internet:
 www.jumo.net

 JUMO Instrument Co. Ltd. JUMO House Temple Bank, Riverway Harlow, Essex, CM20 2DY, UK Phone: +44 1279 63 55 33 Fax: +44 1279 62 50 29 Email: sales@jumo.co.uk Internet: www.jumo.co.uk JUMO Process Control, Inc. 6733 Myers Road East Syracuse, NY 13057, USA Phone: +1 315 437 5866 Fax: +1 315 437 5860 Fmail: info.us@jumo.net Internet: www.jumousa.com



Data Sheet 202670

Page 6/<u>11</u>

Measuring point set-up

The set-up of a complete measuring system for turbidity measurements is shown below. The figure shows a support pillar with pedestal base, cantilever arm, and chain. A JUMO AQUIS 500 RS is used as a display unit / controller, which is mounted on the support pillar and protected by a weather protection canopy (see chapter "Accessories", page 11).

The suspended fitting in image A is attached to the cantilever arm by a chain. Alternatively, an immersion fitting can also be attached to the cantilever arm using a cross clamp, see image B.





- (1) JUMO AQUIS 500 RS display unit / controller, type 202569/...
- (2) Cantilever arm, adjustable
- (3) Cross clamp with 2 clamping levers
- (4) Chain
- (5) Support pillar
- (6) Pedestal base
- (7) Suspended fitting including sensor mounting (9), part no.: 00601881
- (8) Basin/tank/container
- (10) Cross clamp for support pillar (part no. 00605468), required to attach the immersion fitting
- (11) Angled immersion fitting including sensor mounting (9), part no.: 00605469

V2.00/EN/00614747

Support pillar with pedestal base, cantilever arm, and chain Part no. 00398163

Postal address: Phone: Fax: Email: Internet:

Delivery address: Mackenrodtstraße 14 36039 Fulda, Germany 36035 Fulda, Germany +49 661 6003-0 +49 661 6003-607 mail@jumo.net www.jumo.net

JUMO Instrument Co. Ltd. JUMO House Temple Bank, Riverway Harlow, Essex, CM20 2DY, UK +44 1279 63 55 33 Phone: Fax: +44 1279 62 50 29 Email: sales@jumo.co.uk Internet: www.jumo.co.uk

JUMO Process Control, Inc. 6733 Myers Road East Syracuse, NY 13057, USA Phone: +1 315 437 5866 +1 315 437 5860 Fax: Email: info.us@jumo.net Internet: www.jumousa.com



Data Sheet 202670

Page 7/11

Fittings

Suspended fitting

The suspended fitting is used to hold the JUMO ecoLine NTU turbidity sensor and position it at a suitable point in the measurement medium. It is designed to provide the greatest possible protection for the sensor against extraneous light and damage through mechanical influences. The fitting is suspended on a chain, enabling it to follow the movement of the medium in various directions as the water level fluctuates. The fitting is primarily used to take measurements from open channels or basins. Please note the following when planning your set-up:

- The fitting must be easily accessible to allow the sensor and the fitting itself to be maintained and cleaned regularly.
- Do not allow the fitting (and thus also the sensor) to swing against and hit the basin edge.
- When working with systems involving pressure and/or temperature, ensure that the fitting and sensor meet all relevant requirements.
- The system designer must check that the materials in the fitting and sensor are suitable for the measurement (chemical compatibility, for instance).

Suspended fitting			
Materials	Pipe:	PVC	
	Sensor mounting:	PVC	
Temperature range	0 to 60 °C		
Pressure range	Up to 5 bar		
Total length	1,549 mm		
Part no.	00616716		



Fastener with chain holder (1)

(2) Sensor mounting

 Delivery address:
 Mackenrodtstraße 14 36039 Fulda, Germany

 Postal address:
 36035 Fulda, Germany

 Phone:
 +49 661 6003-0

 Fax:
 +49 661 6003-607

 Email:
 mail@jumo.net

 Internet:
 www.jumo.net

 JUMO Instrument Co. Ltd. JUMO House Temple Bank, Riverway Harlow, Essex, CM20 2DY, UK Phone: +44 1279 63 55 33 Fax: +44 1279 62 50 29 Email: sales@jumo.co.uk Internet: www.jumo.co.uk JUMO Process Control, Inc. 6733 Myers Road East Syracuse, NY 13057, USA Phone: +1 315 437 5866 Fax: +1 315 437 5860 Email: info.us@jumo.net Internet: www.jumousa.com



Data Sheet 202670

Page 8/11

Immersion fitting

The immersion fitting is used to hold the JUMO ecoLine NTU turbidity sensor and position it at different immersion depths. The fitting is angled at the lower end, thus keeping rising gas bubbles as far away as possible from the sensor. It also protects the sensor against extraneous light and mechanical influences. The fitting is attached to the support pillar using a cross clamp, see chapter "Measuring point set-up", page 6.

Alongside the standard version with a total length of 3,106 mm, shorter versions are also available on request.

Please note the following when planning your set-up:

- The fitting must be easily accessible to allow the sensor and the fitting itself to be maintained and cleaned regularly.
- Do not allow the fitting (and thus also the sensor) to swing against and hit the basin edge.
- When working with systems involving pressure and/or temperature, ensure that the fitting and sensor meet all relevant requirements.
- The system designer must check that the materials in the fitting and sensor are suitable for the measurement (chemical compatibility, for instance).

Immersion fitting			
Materials	Pipe:	PVC	
	Sensor mounting:	PVC	
Temperature range	0 to 60 °C		
Pressure range	Up to 5 bar		
Total length	3,106 mm	Other lengths	
Part no.	00616717	on request	



(1) Angled end piece

(2) Sensor mounting

 Delivery address:
 Mackenrodtstraße 14 36039 Fulda, Germany

 Postal address:
 36035 Fulda, Germany

 Phone:
 +49 661 6003-0

 Fax:
 +49 661 6003-607

 Email:
 mail@jumo.net

 Internet:
 www.jumo.net

 JUMO Instrument Co. Ltd. JUMO House Temple Bank, Riverway Harlow, Essex, CM20 2DY, UK Phone: +44 1279 63 55 33 Fax: +44 1279 62 50 29 Email: sales@jumo.co.uk Internet: www.jumo.co.uk JUMO Process Control, Inc. 6733 Myers Road East Syracuse, NY 13057, USA Phone: +1 315 437 5866 Fax: +1 315 437 5860 Email: info.us@jumo.net Internet: www.jumousa.com



Data Sheet 202670

Page 9/11

Flow fitting

The flow fitting is used to hold the JUMO ecoLine NTU turbidity sensor. The fitting is mounted directly in the supply line for the medium being measured or in the bypass. Its special design type ensures the correct inflow to the sensor, thus preventing incorrect measurements. Please note the following when planning your piping set-up:

- The fitting must be easily accessible to allow the sensor and the fitting itself to be maintained and cleaned regularly
- It is recommended that the fitting be installed in a bypass with gate valves. This variant allows the sensor to be removed without interference in the process.
- When working with systems involving pressure and/or temperature, ensure that the fitting and sensor meet all relevant requirements.
- The system designer must check that the materials in the fitting and sensor are suitable for the measurement (chemical compatibility, for instance).

PVC flow fitting		
Material	PVC	
Temperature range	0 to 60 °C	
Pressure range	Up to 5 bar	
Connection	Bonded sockets	
Process connection	90° T-piece, DN 40	
Part no.	00616715	



- (1) Flow direction
- (2) Sensor mounting
- (3) Union nut
- (4) JUMO ecoLine NTU sensor

Postal address: Phone: Fax: Email: Internet:

Delivery address: Mackenrodtstraße 14 36039 Fulda, Germany 36035 Fulda, Germany +49 661 6003-0 +49 661 6003-607 mail@jumo.net www.jumo.net

JUMO Instrument Co. Ltd. JUMO House Temple Bank, Riverway Harlow, Essex, CM20 2DY, UK Phone: +44 1279 63 55 33 +44 1279 62 50 29 Fax: Email: sales@jumo.co.uk Internet: www.jumo.co.uk

JUMO Process Control, Inc. 6733 Myers Road East Syracuse, NY 13057, USA Phone: +1 315 437 5866 Fax: +1 315 437 5860 Email: info.us@jumo.net Internet: www.jumousa.com



Data Sheet 202670

Page 10/11

Order details

	(1)	Basic type
202670		JUMO ecoLine NTU
		Optical turbidity sensor
	(2)	Basic type extension
10		Standard, 0 to 4000 NTU
	(3)	Version
8		Standard with factory settings
	(4)	Electrical connection
20		Fixed cable
21		Fixed cable with M12 connector
	(5)	Length of permanent cable
10		10 m
30		30 m
	(6)	Extra code
0		Without



Phone: Fax: Email: Internet:

Delivery address: Mackenrodtstraße 14 36039 Fulda, Germany Postal address: 36035 Fulda, Germany +49 661 6003-0 +49 661 6003-607 mail@jumo.net www.jumo.net

JUMO Instrument Co. Ltd. JUMO House Temple Bank, Riverway Harlow, Essex, CM20 2DY, UK Phone: +44 1279 63 55 33 Fax: +44 1279 62 50 29 Email: sales@jumo.co.uk Internet: www.jumo.co.uk

JUMO Process Control, Inc. 6733 Myers Road East Syracuse, NY 13057, USA Phone: +1 315 437 5866 Fax: +1 315 437 5860 Fax: Email: info.us@jumo.net Internet: www.jumousa.com



Data Sheet 202670

Page 11/11

Scope of delivery

Turbidity sensor with the ordered cable version
Operating manual B 202670.0
Calibration certificate

Stock versions

(Delivery within 3 working days after receipt of order)

Туре	Part no.
202670/10-8-20-10/000	00614965
202670/10-8-20-30/000	00614966

Manufacturing versions

(Delivery within 10 working days after receipt of order)

Туре	Part no.
202670/10-8-21-10/000 (Fixed cable with M12 connector)	00661267

Accessories

(Delivery within 10 working days after receipt of order)

Description	Part no.
Suspended fitting for type 202670/, PVC, total length 1,546 mm	00616716
Immersion fitting for type 202670/, PVC, total length 3,106 mm ^a	00616717
Flow fitting for type 202670/, PVC	00616715

Other lengths on request.

Suitable indicating devices/controllers

Туре	Parts no.
JUMO AQUIS 500 RS	See data sheet 202569
JUMO AQUIS touch S/P	See data sheets 202580/202581
JUMO mTRON T	See data sheets 705000/705001

Accessories for JUMO AQUIS 500RS

Description	Part no.
Support pillar with pedestal base, cantilever arm, and chain	00398163
Additional cross clamp for support pillar, required to attach the immersion fitting	00605468
Pipe-mounted kit for JUMO AQUIS 500 RS	00398162
Weather protection canopy for JUMO AQUIS 500 RS	00398161
Setup program for JUMO AQUIS 500 on CD-ROM	00483602
PC interface with USB/TTL converter, for connecting the PC/laptop to the JUMO AQUIS 500 RS	00456352