

Configurable rotary actuator for butterfly valves

- Torque motor Max. 90 Nm (not constant)
- Nominal voltage AC/DC 24 V
- Control modulating 2...10 V variable
- Position feedback 2...10 V variable
- Running time motor 35 s
- Optimum weather protection for use outdoors





Technical data

Electrical data	Nominal voltage	AC/DC 24 V
	Nominal voltage frequency	50/60 Hz
	Nominal voltage range	AC 19.228.8 V / DC 21.628.8 V
	Power consumption in operation	9 W
	Power consumption in rest position	3 W
	Power consumption for wire sizing	12 VA
	Connection supply / control	Terminals
	Parallel operation	No
Functional data	Torque motor	Max. 90 Nm (not constant)
	Operating range Y	210 V
	Input Impedance	100 kΩ
	Operating range Y variable	Start point 0.530 V
		End point 2.532 V
	Operating modes optional	Open/close
		3-point (AC only)
		Modulating (DC 032 V)
	Position feedback U	210 V
	Position feedback U note	Max. 0.5 mA
	Position feedback U variable	Start point 0.58 V
		End point 2.510 V
	Position accuracy	±5%
	Manual override	with push-button, can be locked
	Running time motor	35 s / 90°
	Running time motor variable	35150 s
	Adaptation setting range	manual (automatic on first power-up)
	Adaptation setting range variable	No action
		Adaptation when switched on
		Adaptation after pushing the manual override button
	Override control	MAX (maximum position) = 100%
		MIN (minimum position) = 0%
		ZS (intermediate position, AC only) = 50%
	Override control variable	MAX = (MIN + 33%)100%
		MIN = 0%(MAX – 33%)
	<u> </u>	ZS = MINMAX
	Sound power level, motor	45 dB(A)
	Position indication	Mechanically (integrated)
Safety data	Protection class IEC/EN	III, Safety Extra-Low Voltage (SELV)
	Power source UL	Class 2 Supply
	Degree of protection IEC/EN	IP66/67
	Degree of protection NEMA/UL	NEMA 4X



Technical data sheet

Safety data	Enclosure	UL Enclosure Type 4X
	EMC	CE according to 2014/30/EU
	Certification IEC/EN	IEC/EN 60730-1 and IEC/EN 60730-2-14
	Mode of operation	Туре 1
	Rated impulse voltage supply / control	0.8 kV
	Pollution degree	4
	Ambient humidity	Max. 95% RH, non-condensing
	Ambient temperature	-3050°C [-22122°F]
	Storage temperature	-4080°C [-40176°F]
	Servicing	maintenance-free
Mechanical data	Connection flange	F07
Weight	Weight	5.5 kg

Safety notes



Ν

- This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application, especially in aircraft or in any other airborne means of transport.
- Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied during installation.
- · Junction boxes must at least correspond with enclosure IP degree of protection!
- The cover of the protective housing may be opened for adjustment and servicing. When it is closed afterwards, the housing must seal tight (see installation instructions).
- The switch for changing the direction of rotation may only be operated by authorised specialists. The direction of rotation must not in particular be reversed in a frost protection circuit.
- The angle of rotation is not permitted to be subjected to mechanical limitation. It is forbidden to alter the mechanical end stops.
- The device may only be opened at the manufacturer's site. It does not contain any parts that can be replaced or repaired by the user.
- The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.
- The device is not designed for applications where chemical influences (gases, fluids) are present or for utilisation in corrosive environments in general.
- The actuator may not be used in plenary applications (e.g. suspended ceilings or raised floors).
- The materials used may be subject to external influences (temperature, pressure, construction fastening, effect of chemical substances, etc.), which cannot be simulated in laboratory tests or field trials. In case of doubt, we definitely recommend that you carry out a test. This information does not imply any legal entitlement. Belimo will not be held liable and will provide no warranty.
- If cables which are not authorised for UL (NEMA) Type 4X applications are used, then flexible metallic cable conduits or suitable threaded cable conduits of equal value are to be used.

Product features

Fields of application	The actuator is particularly suitable for utilisation in outdoor applications and is protected against the following weather conditions: - UV radiation - Rain / Snow - Dirt / Dust - Air humidity - Alternating climate / frequent and severe temperature fluctuations (Recommendation: use the actuator with integrated factory-installed heating which can be ordered separately to prevent internal condensation)
Simple direct mounting	Simple direct mounting on the butterfly valve. The mounting orientation in relation to the butterfly valve can be selected in 90° (angle) increments.



Technical data sheet

_	
Manual override	Manual override with push-button possible (the gear train is disengaged for as long as the button is pressed or remains locked).
	The housing cover must be removed for manual override.
High functional reliability	The actuator is overload protected, requires no limit switches and automatically stops when the end stop is reached.
Torque not constant	Due to the non-linear torque characteristic the actuator can only be used for butterfly valves and not for other armatures.

+-► [°] 90

Accessories

Electrical accessories	Description	Туре
	Auxiliary switch 1 x SPDT add-on	S1A
	Auxiliary switch 2 x SPDT add-on	S2A
	Feedback potentiometer 140 Ω add-on	P140A
	Feedback potentiometer 200 Ω add-on	P200A
	Feedback potentiometer 500 Ω add-on	P500A
	Feedback potentiometer 1 kΩ add-on	P1000A
	Feedback potentiometer 2.8 kΩ add-on	P2800A
	Feedback potentiometer 5 k Ω add-on	P5000A
	Feedback potentiometer 10 k Ω add-on	P10000A
	Heater, with mechanical humidistat	HH24-MG
	Heater, with adjustable thermostat	HT24-MG
Options ex works only	Description	Туре
	Heater, with adjustable thermostat	HT24-MG
	Heater, with mechanical humidistat	HH24-MG

Direction of rotation switch is covered. Factory setting: Direction of rotation Y2.


Electrical installation



0

Supply from isolating transformer.

Wiring diagrams AC/DC 24 V, modulating





- Cable colours: 1 = black
- 2 = red
- 3 = white
- 5 = orange



Functions with basic values (conventional mode)


Override control with AC 24 V with relay contacts







Minimum limit with positioner SG..

Control remotely 0...100% with positioner SG..






Follow-up control (position-dependent)




Functional check


Procedure




1. Connect 24 V to connections 1 and 2 2. Disconnect connection 3: - with direction of rotation Y1: Actuator rotates to the left – with direction of rotation Y2 Actuator rotates to the right 3. Short-circuit connections 2 and 3: - Actuator runs in opposite direction

Override control with AC 24 V with rotary switch





Control with 4...20 mA via external resistor




Caution:


The operating range must be set to DC 2...10 V. The 500 Ω resistor converts the 4...20 mA current signal to a voltage signal DC 2...10 V




Functions with specific parameters (parametrisation necessary)

Override control and limiting with AC 24 V with relay contacts Т







50 Т Close MIN ZS MAX Open (DC 0... **के** रि 0 +e.g. 1N 4007 | 2 T Т Т 3 5 1 d ħ U

Override control and limiting with AC 24 V with rotary switch

1) Caution: This function is only guaranteed if the start point of the operating range is defined as min. 0.5 V.

Operating controls and indicators

þ	9 14" C	Direction of rotation switch
	Y ₂	Switch over: Direction of rotation changes
7	Adaption → 2 Power	Push-button and LED display green
	Status	Off: No power supply or malfunction
4		On: In operation
		Press Triggers angle of rotation adaptation, followed by standard mode button:
3		Push-button and LED display yellow
		Off: Standard mode
		On: Adaptation or synchronisation process active
		Press button: No function
4 Manual override button		
		Press button: Gear train disengages, motor stops, manual override possible
		Release button: Gear train engages, standard mode
	e	Service plug For connecting parametrisation and service tools

2

Check power supply connection


2 Off and **3** On

Possible wiring error in power supply



The actuator can be parametrised by ZTH EU via the service socket. **Tools connection** For an extended parametrisation the PC tool can be connected.

Connection ZTH EU / PC-Tool



Dimensions

