Configurable globe valve actuator for 2-way and 3-way globe valves

- Actuating force 4500 N
- Nominal voltage AC/DC 24 V
- Control modulating 2...10 V variable
- Stroke 50 mm



Technical data

| Electrical data | Nominal voltage | AC/DC 24 V |
|-----------------|------------------------------------|---|
| | Nominal voltage frequency | 50/60 Hz |
| | Nominal voltage range | AC 19.228.8 V / DC 21.628.8 V |
| | Power consumption in operation | 6 W |
| | Power consumption in rest position | 1.5 W |
| | Power consumption for wire sizing | 11 VA |
| | Connection supply / control | Cable 1 m, 4 x 0.75 mm ² |
| | Parallel operation | Yes (note the performance data) |
| Functional data | Actuating force motor | 4500 N |
| | Operating range Y | 210 V |
| | Input Impedance | 100 kΩ |
| | Operating range Y variable | Start point 0.530 V End point 2.532 V |
| | Operating modes optional | Open/close |
| | | 3-point (AC only) |
| | | Modulating (DC 032 V) |
| | Position feedback U | 210 V |
| | Position feedback U note | Max. 0.5 mA |
| | Position feedback U variable | Start point 0.58 V |
| | - | End point 2.510 V |
| | Position accuracy | ±5% |
| | Manual override | with push-button, can be locked |
| | Stroke | 50 mm |
| | Running time motor | 150 s / 50 mm |
| | Running time motor variable | 90150 s |
| | Adaptation setting range | manual (automatic on first power-up) |
| | Adaptation setting range variable | No action |
| | | Adaptation when switched on Adaptation after pushing the manual override |
| | | button |
| | Override control | MAX (maximum position) = 100% |
| | | MIN (minimum position) = 0% |
| | | ZS (intermediate position, AC only) = 50% |
| | Override control variable | MAX = (MIN + 33%)100% |
| | | ZS = MINMAX |
| | Sound power level, motor | 56 dB(A) |
| | Position indication | Mechanically, 550 mm stroke |
| Safety data | Protection class IEC/EN | III, Safety Extra-Low Voltage (SELV) |
| | Power source UL | Class 2 Supply |
| | Degree of protection IEC/EN | IP54 |
| | Degree of protection NEMA/UL | NEMA 2 |



| Technical data sheet | RV24A-MF |
|--|--|
| Enclosure | UL Enclosure Type 2 |
| EMC | CE according to 2014/30/EU |
| Certification IEC/EN | IEC/EN 60730-1 and IEC/EN 60730-2-14 |
| UL Approval | cULus according to UL60730-1A, UL60730-2-14 and CAN/CSA E60730-1 The UL marking on the actuator depends on the production site, the device is UL-compliant in any case |
| Mode of operation | Type 1 |
| Rated impulse voltage supply / control | 0.8 kV |
| Pollution degree | 3 |
| Ambient humidity | Max. 95% RH, non-condensing |
| Ambient temperature | 050°C [32122°F] |

-40...80°C [-40...176°F]

maintenance-free

Weight

Safety data

Weight 3.7 kg

Storage temperature

Servicing

Safety notes



- This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application, especially in aircraft or in any other airborne means of transport.
- Outdoor application: only possible in case that no (sea) water, snow, ice, insolation or
 aggressive gases interfere directly with the device and that it is ensured that the ambient
 conditions remain within the thresholds according to the data sheet at any time.
- Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied during installation.
- The switch for changing the direction of motion and so the closing point may be adjusted only
 by authorised specialists. The direction of motion is critical, particularly in connection with
 frost protection circuits.
- The device may only be opened at the manufacturer's site. It does not contain any parts that can be replaced or repaired by the user.
- Cables must not be removed from the device.
- The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.

Product features

Mode of operation

The actuator is connected with a standard control signal of 0...10 V and drives to the position defined by the control signal. The measuring voltage U serves for the electrical display of the actuator position 0.5...100% and as control signal for other actuators.

Parametrisable actuators

The factory settings cover the most common applications. Single parameters can be modified with the Belimo Service Tools MFT-P or ZTH EU.

Simple direct mounting

Simple direct mounting on the globe valve by means of form-fit hollow clamping jaws. The actuator can be rotated by 360° on the valve neck.

Manual override

Manual override with push-button possible (the gear train is disengaged for as long as the button is pressed or remains locked).

The stroke can be adjusted by using a hexagon socket screw key (5 mm), which is inserted into the top of the actuator. The stem extends when the key is rotated clockwise.

High functional reliability

The actuator is overload protected, requires no limit switches and automatically stops when the end stop is reached.



Home position

Factory setting: Actuator stem is retracted.

When valve-actuator combinations are shipped, the direction of motion is set in accordance with the closing point of the valve.

The first time the supply voltage is switched on, i.e. at the time of commissioning, the actuator carries out an adaptation, which is when the operating range and position feedback adjust themselves to the mechanical setting range.

The actuator then moves into the position defined by the control signal.

Adaptation and synchronisation

An adaptation can be triggered manually by pressing the "Adaptation" button or with the PC-Tool. Both mechanical end stops are detected during the adaptation (entire setting range).

Automatic synchronisation after pressing the manual override button is configured. The

synchronisation is in the home position (0%).

The actuator then moves into the position defined by the control signal.

A range of settings can be adapted using the PC-Tool (see MFT-P documentation)

Setting direction of motion When actuated, the stroke direction switch changes the running direction in normal operation.

Accessories

| Electrical accessories | Description | Туре |
|------------------------|---|---------|
| | Auxiliary switch 2 x SPDT add-on | S2A-H |
| Tools | Description | Туре |
| | Service Tool, with ZIP-USB function, for parametrisable and communicative Belimo actuators, VAV controller and HVAC performance devices | ZTH EU |
| | Belimo PC-Tool, Software for adjustments and diagnostics | MFT-P |
| | Adapter for Service-Tool ZTH | MFT-C |
| | Connection cable 5 m, A: RJ11 6/4 ZTH EU, B: 6-pin for connection to service socket | ZK1-GEN |
| | Connection cable 5 m, A: RJ11 6/4 ZTH EU, B: free wire end for connection to MP/PP terminal | ZK2-GEN |

Electrical installation




Supply from isolating transformer.

Parallel connection of other actuators possible. Observe the performance data.

Direction of stroke switch factory setting: Actuator stem retracted (🛦).

Wiring diagrams

AC/DC 24 V, modulating



Cable colours:

1 = black

2 = red

3 = white

4 = pink


5 = orange




Functions

Functions with basic values (conventional mode)


Override control with AC 24 V with relay contacts




Minimum limit with positioner SG..




Control with 4...20 mA via external resistor




Override control with AC 24 V with Control remotely 0...100% with rotary switch



positioner SG..




Primary/secondary operation (position-dependent)



Functional check




- 1. Apply 24 V to connection 1 and 2
- 2. Disconnect connection 3:
- with upwards direction of motion: closing point at top
- with downwards direction of motion: closing point at bottom
- 3. Short circuit connections 2 and 3:
- Actuator runs in the opposite direction



Caution:


The operating range must be set to DC 2...10 V.

The 500 Ω resistor converts the 4...20 mA current signal to a voltage signal DC 2...10 V




Functions with specific parameters (parametrisation necessary)

Override control and limiting with AC 24 V with relay contacts




Override control and limiting with AC 24 V with rotary switch




1) Caution: This function is only guaranteed if the start point of the operating range is defined as min. 0.5 V.












Operating controls and indicators



Direction of stroke switch

Switch over: Direction of stroke changes

2 Push-button and LED display green

Off: No power supply or malfunction

On: In operation

Press Triggers stroke adaptation, followed by standard mode

button:

3 Push-button and LED display yellow

Off: Standard mode

On: Adaptation or synchronisation process active

Press button: No function

4 Manual override button

Press button: Gear train disengages, motor stops, manual override possible

Release button: Gear train engages, standard mode

5 Service plug

For connecting parametrisation and service tools

10 Manual override


Clockwise: Actuator stem extends
Counterclockwise: Actuator stem retracts




Service

Tools connection The actuator can be parametrised by ZTH EU via the service socket. For an extended parametrisation the PC tool can be connected.

Connection ZTH EU / PC-Tool



Dimensions



Further documentation

- The complete product range for water applications
- Data sheets for globe valves
- Installation instructions for actuators and/or globe valves
- Notes for project planning 2-way and 3-way globe valves
- General notes for project planning