

Bacharach® MGS-400 Gas Detectors



For Safety Compliance in Mechanical Equipment Rooms, Freezers, and Cold Rooms

DESCRIPTION

The MSA Bacharach® MGS-400 Gas Detectors makes compliance with mechanical equipment room and refrigeration safety codes simple and easy, saving time and money on equipment and installation. Using the MGS-400 App, users can intuitively use, commission and maintain their gas detection system without the need for specialty training or tools. Pre-calibrated sensor modules simplify maintenance, take minutes to exchange and do not require the use of calibration gas. The MGS-400 sensors can trigger additional audio-visual alarms and act as a standalone gas detection system, or integrate easily into a BMS / BAS or with MSA's optional Bacharach® MGS-408 Gas Detection Controller.



Features

Mobile App Interface

Pre-calibrated Sensors

Semi-automated Calibration

Remote Sensor Option

Temperature-Compensated Measurement

Low Temperature Performance

Digital Communications

Analog Outputs

Relay outputs

Audio & Visual Alarms

Multiple Cable Entries and Terminals

Benefits

Quick, easy and intuitive commissioning, configuration and maintenance requires no special training. No tools required to set alarm levels and behavior.

Fast and easy sensor maintenance. Eliminates need for calibration gas.

Easy calibration process with mobile app. Generate calibration certificates for documentation.

Locate the sensor element in hard-to-reach areas and the base unit where convenient for electrical and communication wiring (MGS-460)

Mitigates false alarms and optimizes accuracy in refrigeration applications

Suitable for use in cold rooms and freezers down to -40° F/C.

Integrate with local BMS/BAS via Modbus RTU

For current or voltage output to legacy systems (MGS-450/460)

3 relays available for alarm and fault events to active horn/strobes and ventilation (MGS-450, MGS-460)

On-board alarm notification supports compliance with ASHRAE 15 / EN 378

Quick and easy installation of all wiring; daisy-chain power and digital communications

Bacharach® MGS-400 Gas Detectors



Product Configurations		MGS-410	MGS-450	MGS-460
ENCLOSURE RATING		IP66	IP41, IP66	IP66
CONFIGURABLE RELAYS	Settings	n/a	SPDT, Low (1), High (2), Fault (3)	
	Rating		Rating 1 A @ 30 VDC	
DIGITAL COMMUNICATIONS		Modbus RTU		
ANALOG OUTPUT	Single configurable	n/a	4 to 20 mA, 0 to 5 V, 0 to 10 V, 1 to 5 V, 2 to 10 V	
SENSOR		Integrated	Integrated	Remote
SIZE		5.1" × 5.1" × 2.7"	IP41: 6.5" × 6.5" × 3.0" (165 × 165 × 77 mm)	Base Unit: 6.5" × 6.5" × 3.4" (165 × 165 × 87 mm)
		(130 × 130 × 68 mm)	IP66: 6.5" × 6.5" × 3.4" (165 × 165 × 87 mm)	Remote Unit: 4.5" × 5.4" × 2.7" (115 × 136 × 68 mm)
WEIGHT (APPROX)		9.2oz (260 g)	1lb, 1oz (480 g)	1lb, 11.7oz (758 g)

Specifications		MGS-410	MGS-450	MGS-460
GASES AND RANGE	HFC's/HFO	1,000 ppm		
	CO ₂	5,000 / 10,000 / 20,000 / 30,000 / 40,000 / 50,000 ppm		
	NH ₃	100 / 1,000 / 5,000 / 10,000 / 100% LEL		
	O ₂	30 Vol%		
	CO	500 ppm		
	Combustible - Semiconductor (R-290, R-600, R-50, R-600a, R-717)	5,000 ppm		
	Combustible - NDIR (R-600, R-50, R-290)	100% LEL		
	Combustible - Catalytic (R-600, R-50, R-290, R-717)	100% LEL		
	NO ₂	20 ppm		
STATUS INDICATOR		Single Tri-color LED (green, red, orange)		
AUDIO ALARM		Buzzer, 72db @ 10cm		
POWER		24V AC or DC (auto selecting), 4W (max)		
APPROVALS		CE, UL / CSA / IEC EN 61010-1		
AMBIENT CONDITIONS	Temperature			
	Semiconductor	-40 to 122°F / -40 to +50°C		
	Electrochemical	NH ₃ 100 / 1,000 ppm: -40 to 40°C		
		NH ₃ 5,000 ppm: -20 to 40°C CO 500 ppm: -40 to 50°C NO ₂ 20 ppm: -20 to 40°C		
		O ₂ 30% Volume: -20 to 50°C		
	Infrared	-40 to 122°F / -40 to +50°C		
	Catalytic Bead	-40 to 122°F / -40 to +50°C		
Humidity	5 to 90 % RH, non-condensing			
Pressure	23.6 to 32.5 inch Hg / 800 to 1,100 mbar			

Note: This Bulletin contains only a general description of the products shown. While product uses and performance capabilities are generally described, the products shall not, under any circumstances, be used by untrained or unqualified individuals. The products shall not be used until the product instructions/user manual, which contains detailed information concerning the proper use and care of the products, including any warnings or cautions, have been thoroughly read and understood. Specifications are subject to change without prior notice. MSA is a registered trademark of MSA Technology, LLC in the US, Europe, and other Countries. For all other trademarks visit <https://us.msasafety.com/Trademarks>.

MSA operates in over 40 countries worldwide. To find an MSA office near you, please visit [MSAsafety.com/offices](https://us.msasafety.com/offices).