

The Series ADPS/EDPS/BDPA HVAC Differential Pressure Switches are designed for pressure, vacuum, and differential pressures. The dual scaled adjustment knob in inches water column and pascals allows changes to the switching pressure to be made without a pressure gage. The ADPS/EDPS/BDPA are available with settings from 0.08 in w.c. (20 Pa) up to 20 in w.c. (5000 Pa). The silicone diaphragm and PA 6.6 body make the series ADPS ideal for use with air and other noncombustible gases. Series EDPS medials median and are constructed of planum rated plactice. The series EDPS models meet UL508 and are constructed of plenum rated plastics. The series BDPA Adjustable Differential Pressure Alarms offer a versatile range of configurations allowing utilization of their many features including buzzer and LED notification, and battery or line powered. The compact size, adjustment knob and low cost make the ADPS/EDPS/BDPA the perfect choice for HVAC applications.

BENEFITS/FEATURES

- · Adjustment knob changes switching pressure easily with a pressure gage reducing components for application
- · Low cost device makes it an excellent solution in BAS and HVAC applications
- requiring duct control and monitoring Relay contact allows simple integration with DDC or building systems

APPLICATIONS

- · Air filter and ventilator monitoring
- Industrial cooling circuits Fire-protection damper control
- Ventilation duct monitoring Fan heater overheating protection
- Heat exchanger frost protection

MODEL CHART - ADPS				
	Set Point Range	Approx. Dead Band @	Approx. Deadband @	
Model	in w.c. (Pa)	Min Set Point in w.c. (Pa)	Max Set Point in w.c. (Pa)	
ADPS-08-2-N	0.08 to 1.20 (20-300)	0.04 (10)	0.05 (12)	
ADPS-04-2-N	0.12 to 1.60 (30-400)	0.06 (15)	0.09 (23)	
ADPS-03-2-N	0.20 to 2.00 (50-500)	0.08 (20)	0.09 (23)	
ADPS-05-2-N	0.80 to 4.00 (200-1000)	0.4 (100)	0.5 (130)	
		0.6 (150)	0.8 (200)	
ADPS-07-2-N	4.00 to 20.00 (1000-5000)	1.0 (250)	1.4 (350)	
Note: For optic	onal 1/2" NPT conduit conne	ection change -2-N to-1-N I	Models that include installer kit	

add -C to the end of the model number (-2-N cable gland models only). Installer kt includes two static tips and 7 ft of PVC tubing. Order installer kit separately with 1/2" NPT conduit connection models. See A-481 in the accessories list. Consult factory for bulk packaging option.

	Set Point Range	Approx. Dead Band @	Approx. Dead Band @	
Model	in w.c. (Pa)	Min Set Point in w.c. (Pa)	Max Set Point in w.c. (Pa)	
EDPS-08-1-N	0.08 to 1.20 (20-300)	0.04 (10)	0.05 (12)	
	0.12 to 1.60 (30-400)	0.06 (15)	0.09 (23)	
EDPS-03-1-N	0.20 to 2.00 (50-500)	0.08 (20)	0.09 (23)	
EDPS-05-1-N	0.80 to 4.00 (200-1000)	0.4 (100)	0.5 (130)	
EDPS-06-1-N	2.00 to 10.00 (500-2500)	0.6 (150)	0.8 (200)	
EDPS-07-1-N	4.00 to 20.00 (1000-5000)	1.0 (250)	1.4 (350)	
Note: For optional M20 cable gland connection, change -1-N to-2-N.				
MODEL CHART - BDPA				

			Approx. Dead Band @
Model	in w.c. (Pa)	Min Set Point in w.c. (Pa)	Max Set Point in w.c. (Pa)
BDPA-08-2-N	0.08 to 1.20 (20 to 300)	0.04 (10)	0.05 (12)
BDPA-04-2-N	0.12 to 1.60 (30 to 400)	0.06 (15)	0.09 (23)
BDPA-03-2-N	0.20 to 2.00 (50 to 500)	0.08 (20)	0.09 (23)
BDPA-05-2-N	0.80 to 4.00 (200 to 1000)	0.4 (100)	0.5 (130)
		0.6 (150)	0.8 (200)
BDPA-07-2-N	4.00 to 20.00 (1000 to 5000)	1.0 (250)	1.4 (350)

Service: Air and non-combustible, compatible gases. Wetted Materials: ADPS: Diaphragm material: Silicone; Housing material: POM; Switch body: PA 6.6; Cover: Polystyrene; EDPS: Diaphragm material: Silicone; Housing material: Switch body: PA 6.6; Cover: Polystyrene; Materials UL 94 V-0

rated. Temperature Limits: Process and ambient temperature from -4 to 185°F (-20 to 85°C)

Storage: -40 to 185°F (-40 to 85°C).

Pressure Limits: Max. operating pressure: 40 in w.c. (10 kPa) for all pressure range

Switch Type: Single-pole double-throw (SPDT). Electrical Rating: Max. 1.5 A res./0.4 A ind./250 VAC, 50/60 Hz; Max. switching

rate: 6 cycles/min. Electrical Connections: Push-on screw terminals. M20x1.5 with cable strain relief

or optional 1/2" NPT. Process Connections: 5/16" (7.94 mm) outside diameter tubing, 1/4" (6.0 mm) inside diameter tubing

Enclosure Rating: NEMA 13 (IP54).

Mounting Orientation: Vertically, with pressure connections pointing downwards. Mechanical Working Life: Over 10⁶ switching operations. Weight: 4.4 oz (125 g).

Compliance: ETL approved to UL508 and CSA C22.2#14 (EDPS only)

1	ACCESSORIES		
1	Model Description		
	A-288 A-289	"L" type metal mounting bracket with screws "S" type metal mounting bracket with screws	
	A-481	Plastic static pressure tip Installer kit, includes 2 plastic static pressure tips and 7' (2.1 m) of PVC tubing	
	A-489	(2.1 m) of PVC tubing 4″ straight static pressure tip with flange	

A-480

Process Tubing Options: See page 453 (Gage Tubing Accessories)

PRESSURE