

TECHNICAL DATA



Specifications

Measuring Range:	6 - 99.9% M.C.
Accuracy:	±1%
Resolution:	0.1%
Temperature:	-31 to 176°F (-35 to 80°C)
Sensor Type:	Contact Pins
Display:	LCD Display
Replaceable Pins:	Yes
Auto Shut-off:	Yes (user selectable between 1 and 9 mins)
Low Battery Indicator:	Yes
Power Supply:	2x AAA Batteries
Product Certifications:	CE
Operating Temperature:	32 to 104°F (0 to 40°C)
Storage Temperature:	14 to 140°F (-10 to 60°C)
Operating Humidity:	0-85%
Dimensions:	7 x 1.9 x 2" (180 x 50 x 31mm)
Weight:	6.1 oz (175g)

Features

- Measures wood moisture with integrated pins or with remote hand-press probe
- Improved accuracy with use of included automatic temperature compensation probe
- Memory contains 8 wood groups with calibrations for approx. 170 species of wood
- Built-in 2-point calibration check
- Low battery indicator and auto shut-off
- Includes remote hand-press moisture electrode, ATC temperature probe, protective cap, replacement pins, soft carrying case, and batteries



Model	Description
R6015	Wood Moisture Detector
R6015-P	Replacement Electrode Pin
R6015-NIST	Wood Moisture Detector & NIST