

Digital multimeter

testo 760-1
testo 760-2
testo 760-3

Easy, modern operation with function keys instead of a dial

Measurement parameter detection and selection via the socket assignment

Prevents incorrect settings

True root mean square measurement - TRMS

Large, backlit display



The testo 760 digital multimeter family comprises three models for all important electrical measuring tasks. Function keys replace the traditional dial on all three instruments, which means easier operation and greater reliability. Incorrect settings are now impossible, because the measurement parameters are detected automatically via the assignment of the measuring sockets and also shown by the illumination of the appropriate function keys.

The testo 760-1 model is the standard version for virtually all daily measuring tasks. The testo 760-2 is differentiated by a larger current measurement range, the true root mean square measurement - TRMS - and a low-pass filter. The testo 760-3 is the model with the highest specification and, in addition to the features of the other two models, it has a voltage range of up to 1000 V, along with higher measuring ranges for frequency and capacitance.

Technical data/accessories

testo 760-1

testo 760-1, multimeter, including batteries and 1 set of measuring cables

Order no. 0590 7601



testo 760-2

testo 760-2, TRMS multimeter, including batteries, 1 set of measuring cables and 1 x adapter for type K thermocouples

Order no. 0590 7602



testo 760-3

testo 760-3, TRMS multimeter, including batteries and 1 set of measuring cables

Order no. 0590 7603



Technical data	testo 760-1	testo 760-2	testo 760-3
True RMS	–	✓	
Basic accuracy	0.8 %	0.1 %	
Voltage measuring range	0.1 mV to 600 V AC/DC		0.1 mV to 1000 V AC/DC
Current measuring range	1 mA to 10 A AC/DC	0.1 µA to 10 A AC/DC	
Resistance measuring range	0.1 to 40 MΩ	0.01 to 60 MΩ	
Frequency measuring range	0.001 Hz to 512 kHz	0.1 Hz to 60 MHz	
Capacitance measuring range	0.01 nF to 100 µF	0.001 nF to 60 mF	
Temperature measuring range	–	-20 to +500°C	
Continuity testing	✓		
Diode test	✓		
Display (counts)	4,000	6,000	
Measurement category	CAT III 600 V	CAT IV 600 V	CAT IV 600 V CAT III 1000 V
Protection class	IP 64		
Operating temperature	-10 to +50 °C		
Storage temperature	-15 to +60 °C		
Dimensions	167 x 85 x 45 mm (L x W x H)		
Weight	340 g		
Authorizations	CSA, CE		
Standards	EN 61326-1, EN 61010-2-033, DIN EN 61140		

testo 760-1/-2/-3 accessories

Order no.

Magnetic hook	0590 0001	
Set of safety crocodile clips, suitable for 0590 0011 and 0590 0012	0590 0008	
Set of crocodile clips, suitable for 0590 0010	0590 0009	
Set of 2 mm measuring cables (angled plug), suitable for 0590 0009	0590 0010	
Set of 4 mm standard measuring cables (angled plug), suitable for 0590 0008	0590 0011	
Set of 4 mm standard measuring cables (straight plug), suitable for 0590 0008	0590 0012	
Set of measuring cable extensions (straight plug)	0590 0013	
Set of measuring cable extensions (angled plug)	0590 0014	
testo 760 transport bag	0590 0016	
ISO calibration certificate multimeter	0520 0760	
DAkkS calibration certificate multimeter	0520 0761	

testo 760-1/-2 accessories

Order no.

Set of 5 x 10 A/600 V spare fuses	0590 0005	
Set of 5 x 630 mA/600 V spare fuses	0590 0007	

testo 760-2/-3 accessories

Type K thermocouple adapter	0590 0002	
Current probe adapter	0590 0003	

testo 760-3 accessories

Set of 5 x 10 A/1,000 V spare fuses	0590 0004	
Set of 5 x 630 mA/1,000 V spare fuses	0590 0006	