

TECHNICAL DATA

Fluke 700PTPK2 Pneumatic Test Pressure Kit



Product overview: Fluke 700PTPK2 Pneumatic Test Pressure Kit

Rugged, high-quality premium pneumatic pressure pump kit for fast and accurate test results generates pressure up to 600 psi, 40 bar. Includes the 700PTP-1 pneumatic hand pump, premium test hoses and adapters, and protective hard case.

- Combine with any Fluke 700G Series Gauge, 1,000 psi (69 bar) or less, to make a complete pressure testing kit
- Generate pressure up to 600 psi, 40 bar with the 700PTP-1 test pump
- Connect the 700G Series Gauge directly to the included PTP-1 hand pump with premium no tools required adapter
- Includes 700TTH 5K premium/no tools required transmitter test hose kit and adapters for connecting to the pressure device to be tested
- Hard case protects pump and gauge and allows gauge to remain connected to the pump

Ordering information



Fluke 700PTPK2

Includes:

- 700PTP-1 pump
- Premium, no tools required gauge connector
- One (1) premium transmitter test hose kit and adapters
- Hard case

Fluke. *Keeping your world up and running.®*

Fluke Corporation
PO Box 9090, Everett, WA 98206 U.S.A.

For more information call:
In the U.S.A. (800) 443-5853
In Canada (800) 36-FLUKE
From other countries +1 (425) 446-5500
www.fluke.com

©2023 Fluke Corporation.
Specifications subject to change without notice.
08/2023

**Modification of this document is not permitted
without written permission from Fluke Corporation.**